



CHAFING DISH

1. Remove the chafing dish cover and the food inserts. Fill the water pan of the chafing dish to a level of about 20-25mm with hot water. Replace the filled food inserts and put the lid back on top to hold the heat in.
2. Open the Fuel Holder and remove the cap from the top of the solid fuel, replace the top of the fuel holder and place in its position in the tray below the water pan with the sliding cap open.
3. Light the solid fuel. Use the sliding cap on top of the fuel holder to regulate the amount of heat output and put out the flame when you are finished.

Note: Each Canned Heat solid fuel will burn for approximately 2 hours.

WARNING!

DO NOT TRY TO OPERATE THE CHAFING DISH WITHOUT WATER IN THE WATER PAN. IT WILL NOT WORK AND YOU WILL BE LIABLE FOR ANY DAMAGE CAUSED TO THE CHAFING DISH.

www.aabco.com.au

12 Citrus Street, Braeside, Vic. 3195

Tel: 9587 8799